

京中台

寸法	高x巾x奥mm
2, 5	127x59x32
3, 0	153x68x38
3, 5	173x74x41
4, 0	190x82x42
4, 5	217x87x44
5, 0	233x92x46
5, 5	255x94x50
6, 0	278x99x54
7, 0	322x115x56
8, 0	362x125x64
9, 0	413x138x77
10, 0	462x154x83
2. 5x5. 0	235x115x53
2. 5x6. 0	278x118x55
2. 5x7. 0	324x124x58
3. 0x7. 0	326x142x63
3. 5x7. 5	349x157x63
4. 0x8. 0	372x180x69
5. 0x9. 0	425x220x80
6. 0x10. 0	470x254x86
7. 0x11. 0	515x295x89
8. 0x12. 0	557x333x95

京中台 中巾

寸法	高x巾x奥mm
1.5x3.0	150x70x37
1.8x3.5	175x85x43
2.0x4.0	195x95x42
2.0x4.5	212x94x42
2.0x5.0	240x98x49
2.2x4.5	220x103x45
2.2x5.0	237x102x43
3.0x6.0	282x133x56
3.5x6.0	280x150x54
4.0x6.0	282x165x55