

千倉座

寸法	高x巾x奥mm
2, 5	130x56x31
3, 0	157x66x37
3, 5	175x75x41
4, 0	200x80x41
4, 5	222x87x47
5, 0	241x91x49
5, 5	264x100x52
6, 0	282x102x58
7, 0	329x115x58
8, 0	368x127x65
9, 0	420x138x79
10, 0	465x155x82
2. 5x5. 0	249x118x55
2. 5x6. 0	281x118x57
2. 5x7. 0	322x122x60
3. 0x7. 0	331x140x62
3. 5x7. 5	353x156x64
4. 0x7. 0	335x172x64
4. 0x8. 0	380x183x70
5. 0x9. 0	432x220x80
6. 0x10. 0	475x258x85
7. 0x11. 0	523x295x92
8. 0x12. 0	561x335x98

千倉座 中巾

寸法	高x巾x奥mm
1.5x3.0	160x71x38
1.8x3.5	182x87x41
2.0x4.0	200x93x41
2.0x4.5	222x93x41
2.0x5.0	236x93x45
2.2x4.5	226x107x45
2.2x5.0	241x103x45
3.0x6.0	289x135x53
3.5x6.0	290x150x53
4.0x6.0	292x165x55